

SUMMARY	Delta T	DST	SRC	SUMMARY	Delta T	DST	SRC		
115		[206.66.184.2..	<<[1	115		[206.66.184.2..	<<[1		
118	0.11654	[161.69.7.166]	<<[2	118	0.11654	[161.69.7.166]	<<[2		
131	0.72744	[161.69.7.166]	<<[2	131	0.72744	[161.69.7.166]	<<[2		
132	0.00040	[206.66.184.2..	<<[1	132	0.00040	[206.66.184.2..	<<[1		
133	0.00255	[161.69.7.166]	<<[2	133	0.00255	[161.69.7.166]	<<[2		
Frame 118 of 546				Frame 115 of 546					
DETAIL				DETAIL					
TCP: ----- TCP header -----				HTTP: ----- Hypertext Transfer Proto					
TCP:				HTTP:					
TCP: Source port = 80 (HTTP: Line 1: GET /discuss/bin/nph					
TCP: Destination port = 2655				HTTP: &message=1&mag=pcmag					
TCP: Sequence number = 9425				HTTP: %20Pentium HTTP/1.0					
Frame 118 of 546				Frame 115 of 546					
HEX				HEX					
ASCII				ASCII					
0000 00 60 8C C8 9C C0 00 00				0000 00 00 81 04 0A 1F 00 60					
0008 81 04 0A 1F 08 00 45 00E.				0008 8C C8 9C C0 08 00 45 00E.					
0010 00 28 58 19 00 00 2C 06 .(X.				0010 01 BF 80 CE 40 00 20 06 @. .					
0018 06 C0 CE 42 B8 C9 A1 45 . . .B. . .E				0018 A8 73 A1 45 07 A6 CE 42 .s.E. . .B					
0020 07 A6 00 50 0A 5F 38 2E . . .P. _8.				0020 B8 C9 0A 5F 00 50 19 24 . . . _ .P.\$					
Frame 118 of 546				Frame 115 of 546					
Use TAB to select windows									
1	2 Set	3Expert	4 Zoom	5	6Disply	7 Prev	8 Next	9Select	10 New
Help	mark	window	in	Menus	options	frame	frame	frame	capture

Figure 7-17. Displaying Interpreted Frames in all Three Views